


- Top:** 3onic Logo
- Bottom:** two recessed contacts to operate
- Front:** micro-USB socket + LED charge-control
- Operation:** touch both contacts at the same time

Schnurrer®  
Quick-Manual



- On:** touch until device starts pouring
- Switch:** cat/kitty/my-cat: touch briefly
- Off:** touch until device switches off
- Charge:** plug cabel logo facing up into micro-USB